

Installation instructions

Akrapovič Exhaust System **Evolution** for the **Aprilia RSV4 Aprilia Tuono V4** Congratulations on purchasing the Akrapovič exhaust system.

Please read this entire installation manual carefully prior to installing and using the Akrapovič exhaust system.

Akrapovič <u>exhaust system should only be installed by persons skilled in motorcycle</u> exhaust system installation and performance. The instructions provided in this manual should be followed to ensure proper installation and safe use of the Akrapovič exhaust system. Akrapovič and/or its partners shall not be held liable for any damage or personal injury (including direct, indirect, or consequential damage) sustained as a result of improper installation of the Akrapovič exhaust system or its use and maintenance contrary to the instructions and warnings contained herein.

If you have any questions regarding the installation and/or proper use of the Akrapovič exhaust system or this manual, please contact your local Akrapovič partner.

GENERAL INFORMATION

Your safety is our number one priority. Please ride your motorcycle responsibly, safely and always obey local traffic rules.

All statements made with regard to the exhaust system's compliance are made in respect of the exhaust system "as is". Any modifications of the Akrapovič exhaust system or its improper installation, use or maintenance that is not in accordance with this Installation manual, may result in severe damage to the exhaust system and/ or engine, as well as personal injury, and may affect the exhaust system's compliance with the legal requirements, such as exhaust system's air and/ or noise emissions (as an example, the motorcycle may not be suitable for use on public roads any longer), as well as warranty coverage.

The exhaust system may only be used in accordance with relevant laws and regulations, including state and federal, where applicable.

Damage caused by improper installation, use and maintenance of the Akrapovič exhaust system is not covered by the Akrapovič warranty. Please refer to the enclosed warranty with regard to the terms of our warranty.

Technical specifications of Akrapovič exhaust systems and related products are subject to change without notice.

COPYRIGHT AND OTHER RIGHTS NOTICE

The Akrapovič trademark, including corporate logos and emblems, are subject to copyright as well as trademark rights of Akrapovič, its licensors, or third persons authorizing Akrapovič to use them.


Any reproduction, technical or other manipulation, translation, or other use of the copyright and/or trademark rights contained herein is prohibited without the explicit prior written consent of Akrapovič. The same especially applies to the entire contents of this manual and/or any of its parts, including but not limited to technical specifications, instructions, graphs, photographs, and so on included in this manual.

The shape of the exhaust system is protected under a registered Community Design No. RCD 002747329-0001.

SAFETY AND COMPLIANCE WARNING, PLEASE READ CAREFULLY

BEFORE REMOVING THE STOCK EXHAUST SYSTEM AND BEGINNING THE INSTALLATION OF YOUR NEW AKRAPOVIČ EXHAUST, PLEASE MAKE SURE THAT ALL ITEMS LISTED BELOW ARE VERIFIED:

- THIS MANUAL IS SPECIFIC TO THE MOTORCYCLE INDICATED ON THE COVER PAGE, FOR WHICH IT IS DESIGNED. INSTALLATION PROCEDURES VARY DEPENDING ON THE TYPE OF MOTORCYCLE. PLEASE VERIFY THAT THE AKRAPOVIČ EXHAUST SYSTEM AND THIS INSTALLATION MANUAL CORRESPOND TO THE TYPE OF YOUR MOTORCYCLE.
- THE EXHAUST SYSTEM CAN GET EXTREMELY HOT DURING AND AFTER IT IS USED. MAKE SURE NOT TO TOUCH THE EXHAUST SYSTEM UNTIL IT IS COMPLETELY COOL. ALLOW THE EXHAUST AND ENGINE TO COOL DOWN BEFORE BEGINNING INSTALLATION OR ANY OTHER WORK ON THE EXHAUST SYSTEM.
- MAKE SURE THE MOTORCYCLE IS **SECURELY POSITIONED TO PREVENT TIPPING OVER** AND DAMAGE TO YOURSELF AND OTHERS, OR THE MOTORCYCLE.
- PLEASE CHECK THE PARTS YOU RECEIVED AGAINST THE PARTS LIST AVAILABLE ON OUR WEBSITE. MAKE SURE THAT YOU HAVE ALL THE PARTS NECESSARY FOR THE INSTALLATION OF YOUR NEW AKRAPOVIČ EXHAUST SYSTEM. IF ANY OF THE PARTS IS MISSING, PLEASE DO NOT PROCEED WITH UNINSTALLING YOUR STOCK EXHAUST SYSTEM/ INSTALLING THE AKRAPOVIČ EXHAUST SYSTEM AND CONTACT THE RETAILER WHERE YOU PURCHASED THE AKRAPOVIČ EXHAUST SYSTEM.
- ALWAYS SECURE YOUR MOTORCYCLE'S GROUND CLEARANCE. FOR ADVANCED USERS, WE RECOMMEND YOU CHECK THE MOTORCYCLE SPRING PRELOAD SETTINGS TO OPTIMIZE GROUND CLEARANCE WHERE POSSIBLE.
- EVERY EXHAUST SYSTEM MUFFLER HAS ITS UNIQUE SERIAL NUMBER, WHICH IDENTIFIES THE AUTHENTICITY OF THE PRODUCT. YOU CAN FIND THE SERIAL NUMBER ON THE MUFFLER'S INLET PIPE. PLEASE REFER TO THE PICTURE BELOW. PLEASE VERIFY THAT YOUR EXHAUST SYSTEM IS AN ORIGINAL AKRAPOVIČ PRODUCT. IF YOU HAVE ANY DOUBTS, PLEASE CONTACT THE RESELLER WHERE YOU PURCHASED THE EXHAUST SYSTEM OR AKRAPOVIČ PARTNERS. THIS MANUAL, ANY CERTIFICATES AND AKRAPOVIČ WARRANTY APPLY TO ORIGINAL PRODUCTS ONLY.





SERIAL NUMBER POSITION



NOISE AND EMISSION WARNINGS

General warning

Because of the world-wide distribution of Akrapovič d.d. products, neither Akrapovič d.d. nor any of its subsidiaries make any representation that the products comply with the air and/or noise emissions laws, or labeling laws, of any jurisdiction. The purchasers are entirely responsible for informing themselves of the applicable laws where the products are to be used and to comply with those law.

Although legal compliance of Akrapovič products in a specific country should be determined by the user, you can find some basic guidance on compliance of your Akrapovič exhaust system with various legal requirements on the product-related part of our website. For EC and ECE type approvals, please refer to the certificate enclosed to your product.

USA WARNING

Various U.S. states and the U.S. federal government have individual laws regulating the use of aftermarket exhaust parts and systems, especially as those parts and systems modify, remove, or replace original equipment catalysts. Please consult the appropriate laws in your area before installing any aftermarket part or system on your vehicle to ensure compliance with all applicable laws. Neither Akrapovic d.d. nor any of their subsidiaries or the sellers of the parts or systems make any representation that any of their parts or systems comply with any such laws.

CALIFORNIA WARNING

California laws prohibit the use of any aftermarket exhaust part or system that modifies, removes or replaces original equipment catalysts unless the California Air Resources Board has issued an Executive Order regarding such part or system or unless the part or system is exempted by being used only on racing vehicles on closed courses. Neither Akrapovic d.d. nor any of their subsidiaries make any representation that any of their parts or systems has received such an Executive Order or that any of their parts or systems conform with the racing vehicles exemption. The purchasers are entirely responsible for informing themselves of applicable California laws and to comply with those laws.

GENERAL NOTE

Photographs and other illustrations in this manual are symbolic and are intended to help represent individual steps for proper installation and use, as well as for a general overview. The actual component parts of the Akrapovič exhaust system may not entirely correspond to the photographs and other illustrations.

SYMBOLS

The following symbols are used throughout these installation instructions:

o e	TOOLS AND PROTECTIVE EQUIPMENT REQUIRED		TIGHTENING TORQUE
66	LUBRICATION		HAND TIGHTEN
X	INSTALLATION TIP	!	CAUTION OR IMPORTANT

USE BOLT SEALANT

Apply 3 to 4 small drops of bolt sealant onto the cleaned and degreased threads before tightening the bolts.

WARNING! Avoid contact with skin, eyes and mucous membranes. Do not inhale fumes. Keep out of reach of children.



USE ANTI-SEIZE LEAD-FREE COPPER PASTE (black tube)

Provides trouble-free and long-lasting protection against seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Also protects against vibration, wear and impact.


WARNING! Avoid eye contact. Keep out of reach of children.



USE ANTI-SEIZING GREASE (white tube)

Prevents seizing, corrosion and excessive wear between the titanium components of your exhaust system.

WARNING! Avoid eye contact. Keep out of reach of children.



PARTS LIST

The following parts should be found in the box:

- Installation Manual
- Homologation certificate/ compliance documents if applicable
- Warranty
- Fitting material
- Muffler and pipes

REMOVAL OF STOCK EXHAUST SYSTEM:

The process of uninstalling the original exhaust system may vary depending on the existing exhaust system. Please follow the original exhaust system manufacturer's instructions for uninstalling the original exhaust system.

If you for any reason decide otherwise, please note that any information provided in this respect herein should be considered as general information provided for your convenience only. Akrapovič shall not assume any liability or responsibility with regard to uninstalling your existing exhaust system, warranty coverage of such exhaust system or vehicle or their further fitness for use.

In case your Akrapovič exhaust system may not be used on certain roads or under certain conditions, please keep the stock or other exhaust system that you can use in such circumstances legally.

ECU fuel-mapping enrichment

Please make sure that any ECU fuel-mapping enrichment is compliant with relevant laws, including state and federal, where applicable. Akrapovič makes no representation or warranty with regard to legal compliance, noise or gas emissions in case of ECU fuel-mapping enrichment.

Evolution

For perfect performance, throttle response and durability of the engine, the Akrapovič Evolution exhaust system should be used in combination with ECU fuel mapping enrichment provided by a professional, to avoid severe engine damage or breakdown, which could result in injury.



REMOVAL OF STOCK EXHAUST SYSTEM:

- Put the motorcycle on a side stand, we recommend a central racing stand. Make sure, that surface is solid and flat.
 Unscrew marked bolts and carefully remove heat shield off the motorcycle (F 01).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!




- 3. Unscrew marked bolt and loosen marked clamp (F 02, 03).
- IMPORTANT: be careful not to damage any part of the motorcycle during this procedure!





- 4. Partially remove stock muffler, as shown and remove valve cables off the bracket and muffler. Carefully remove stock muffler off the motorcycle (F 04).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!





- 5. Remove the metal collar and rubber damper from the muffler hanging bracket (F 05).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!



- 6. Unscrew marked bolts, remove plastic fasteners on both sides of the motorcycle and carefully remove the lower and middle parts of the cowling (F 06, 07, 08, 09).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!











- 7. Disconnect electrical connector from the valve actuator. Unscrew marked bolts and partially remove valve actuator (F 10).
- IMPORTANT: be careful not to damage any part of the motorcycle during this procedure!



- 8. Disconnect exhaust valve cables and carefully remove the cables from the motorcycle (F 11, 12).
- IMPORTANT: be careful not to damage any part of the motorcycle during this procedure!







9. Assemble and reinstall the valve actuator, without cables, onto the motorcycle in reverse order as it was removed. Check vehicle manufacturer manual for tightening torques (F 13, 14).

IMPORTANT: be careful not to damage any part of the motorcycle during this procedure!





- 10. Unscrew the bolt and remove the safety pin from the oil cooler hanging brackets and move the cooler out of the way (F 15).
- IMPORTANT: be careful not to damage the radiator or any other part of the motorcycle during this process!



- 11. Unhook the marked springs (F 16).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!







- 12. Unscrew both lambda sensors, unhook the marked springs and carefully remove the collector off the motorcycle (F 17, 18).
- IMPORTANT: make sure not to damage the lambda sensor's electrical lead during this procedure!
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!



IMPORTANT: make sure not to damage the lambda sensor's electrical lead during this procedure!



- 13. Unscrew the rear headers' flange nuts and carefully remove the headers off the motorcycle (F 19).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!



- 14. Unscrew the front headers' flange nuts and carefully remove the headers off the motorcycle (F 20).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this procedure!





INSTALLATION OF THE AKRAPOVIČ EXHAUST SYSTEM:


 Set up the flanges together with the springs and sleeves; make sure you orient the flanges and springs as shown (F 21).




2. Set up the **left rear header** with flange, spring and sleeve; make sure you orient the flange and spring as shown **(F 22)**.



- 3. Set up and tighten the front header's flanges together with the springs and sleeves onto the front cylinder head, using stock nuts; make sure you orient the flanges and springs as shown (F 23).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this process!
- **X** INSTALLATION TIP: use new stock exhaust port gaskets.




- 4. Set up and tighten the (rear right only!) header's flange together with the spring and sleeve onto the rear right cylinder head outlet, using stock nuts; make sure you orient the flange and spring as shown (F 24).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this process!
- **INSTALLATION TIP:** use new stock exhaust port gasket.






- 5. Instal the **left rear header** together with sleeve, flange and spring; tighten the flange onto the rear cylinder head, using stock nuts and attach the spring (F 25).
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this process!

X INSTALLATION TIP: use new stock exhaust port gasket.




- 6. Insert the right rear header into the sleeve and attach the spring (F 26).
- IMPORTANT: make sure, that spring pull the header tube all the way into the sleeve use rubber mallet if necessary to tap the connection into place!
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this process!



- 7. Insert the front headers into the sleeves and attach the springs (F 27).
- IMPORTANT: make sure, that springs pull the header tubes all the way into the sleeves use rubber mallet if necessary to tap the connections into place!
- CAUTION: be careful not to injure yourself or damage any part of the motorcycle during this process!



- 8. Assemble the collector onto the headers and install the lambda sensors into the collector (F 28).
- ✗ INSTALLATION TIP: coat the interior side of the inlet bushes of the titanium collector with Akrapovič ceramic anti-seizing grease (white tube).
- INSTALLATION TIP: use ceramic anti-seizing grease on the lambda sensor threads (white tube).





- 9. Attach the springs at the rear and front headers collectors joints (F 29, 30).
- IMPORTANT: make sure, that springs pull the collector all the way onto the headers use rubber mallet if necessary to tap the connections into place!






- 10. Slide the link pipe onto the collector's outlet and attach the spring (F 31).
- IMPORTANT: make sure, that spring pull the link pipe all the way onto the collector use rubber mallet if necessary to tap the connection into place!
- ✗ INSTALLATION TIP: coat the interior side of the input bush of the titanium link pipe with Akrapovič ceramic anti-seizing grease (white tube).



- 11. Unscrew marked bolts on both sides and remove passenger's foot rests off the motorcycle (F 32).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!






- 12. Install the Carbon Fiber Bracket onto the right side of the sub frame, using bolts, washers and Aluminium distance bushes from Akrapovič installation kit (F 33).
- IMPORTANT: use bolt sealant on the bolt threads!




- 13. Correctly position the carbon-fiber clamp (check the position of the yellow sticker) and carefully slide it onto the muffler (F 34).
- IMPORTANT: open the carbon-fiber clamp slightly wider than the diameter of the outer sleeve of the muffler - do not scrape it along the muffler outer sleeve!



- 14. Position the muffler correctly, slide it onto the outlet of the link pipe and attach the springs (F 35).
- IMPORTANT: be careful not to damage the muffler or any other part of the motorcycle during this process!
- **INSTALLATION TIP:** coat the interior side of the inlet bushes of the muffler with Akrapovič ceramic antiseizing grease (white tube).




- 15. Hand tighten the carbon-fiber clamp onto the muffler's bracket, using bolt, nut and washer from installation kit and stock Aluminium washer (F 36).
- IMPORTANT: be careful not to damage any part of the motorcycle or exhaust system during this process!
 IMPORTANT: hand tighten the bolt only!





16. Align the muffler in respect to the motorcycle and tighten the muffler's bracket bolt to the specified torque (F 37).

IMPORTANT: be careful not to damage any part of the motorcycle or exhaust system during this process!



- 17. Reinstall all dismounted stock parts and cowlings in the reverse order from the order in which they were removed **(F 38).**
- **INSTALLATION TIP:** check vehicle manufacturer manual for tightening torques!
- CAUTION: be careful not to damage any part of the motorcycle during this process!



FINAL INSTALLATION AND MAINTENANCE:

Clean grease spots off all exhaust system surfaces, when installation is finished. Cleaning will prevent spots from burning onto the surface. Do not use aggressive chemical cleaners, because they can damage the surface or sticker.

- 1. Muffler titanium outer sleeve: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40[®] or equivalent)*.
- 2. Muffler carbon-fiber outer sleeve: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 3. Muffler carbon-fiber outlet cap: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 4. Painted mufflers and parts use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 5. Chrome plated mufflers and parts: use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 6. Stainless steel pipes: use a soft cloth sprayed with a contact cleaner, then wipe with a soft dry cloth.
- 7. Titanium pipes: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40[®] or equivalent)*.

*WD-40 $^{\textcircled{R}}$ is a trademark of the WD-40 Company.

Periodically make sure all the bolts and springs are sufficiently tight.

- IMPORTANT: make sure all the bolts are sufficiently tightened. In case the exhaust system touches the cowling or other parts repeat the adjustment of the exhaust system or contact your authorized dealer!
- CAUTION: after running engine for 30 minutes, retighten the bolts of the Akrapovič carbon-fiber
 heat shield!
- **INSTALLATION TIP: IT IS NORMAL IF WHITE SMOKE COMES OUT OF THE MUFFLER DURING THE FIRST 100 KM AFTER REPLACEMENT.**
- **INSTALLATION TIP: A CHANGE IN THE COLOR OF THE EXHAUST SYSTEM IS NORMAL DUE TO THE HIGH TEMPERATURES.**
- CAUTION: DO NOT STAND BEHIND THE MUFFLER AT ANY TIME.
- IMPORTANT: DO NOT USE AUTOMOTIVE WHEEL CLEANERS OR ANY CLEANING PRODUCTS WHICH CONTAIN ACIDIC ADDITIVES TO CLEAN AKRAPOVIČ EXHAUST SYSTEMS.

TROUBLESHOOTING:

Problem	Possible cause	Solution
Exhaust gas leaks out of the muffler/pipe clamp connections	loosened clamp	tighten the clamp to specified torque
	connection is not completely joined	tap the connection into place and tighten the clamp to specified torque

