





Axle Pull Instructions



23-055 Front Axle Pull

1 Using a 27mm socket, remove the front axle nut. With a 10mm socket unthread the plastic plug out from the inside of the axle. (Figure 1) With a long rod or screw driver, (Figure 2) tap out the aluminum plug from the end of the right side of the axle. (Figure 3)

2 Apply a small amount of thread lock to the threads of the supplied 6x45mm center bolt. Insert the supplied 6x45mm center bolt through the axle pull handle and thread it into the star nut. Only thread the bolt in until the end of the bolt is even with the end of the star nut. (Figure 4) Do not thread the bolt in further than the end of the star nut. Note: The lock tabs on the star insert must angle back towards the axle pull as shown in figure 4.

3 Hold the axle pull assembly up to the right side of the front axle as shown in (Figure 5). Insert the star nut into the hollow portion of the axle by tapping the end of the center bolt with a dead blow hammer until the center bolt bottoms in the center of the axle pull handle with the axle pull handle up against the axle.

4 Rotate axle pull handle behind the fork leg and then tighten axle pull using a 5mm Allen wrench or t-handle. (Figure 6) Re-install the front axle nut and torque it to the motorcycle manufacturer's specifications.

23-056 Rear Axle Pull

1 With a small screw driver pry out the plastic plug from the end of the left side of the axle. (Figure 7) Be sure to de bur the hole.

2 Apply a small amount of thread lock to the threads of the axle pull. Insert axle pull into the left side of the rear axle and rotate the handle near the top of the swing arm as shown in (Figure 8).

3 Tighten axle pull using a 5mm Allen wrench or t-handle.

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer.5 2 08

Enduro Engineering

QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Axle Pull

Part# 23-055, 23-056