

A Division of Thiessen Products, Inc.

INSTRUCTION SHEET FOR TOOL NO.2388

TOOL DRIVER SPACER Use with driver tools No. 33071-73, 94547-80A, 94547-80B Use with JIMS® Tool handle No. 33416-80



- 1. Refer to H-D Service Manual for specifications.
- 2. Place half of tool into bearing race one at a time.
- With both halves inserted into the bearing race, install tool driver spacer in between halves of tool.
- 4. Install JIMS No. 33416-80 handle into the hole in driver spacer, press out the race.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

When it comes to guality motorcycle tools, JIMS is the brand you can depend on.