MANUAL





M1^{PRO}

THANK YOU FOR PLACING YOUR TRUST,

In our decades of experience in the development and manufacture of motorcycle helmets. We're delighted that you have chosen the SCHUBERTH M1 PRO. Each and every M1 PRO that leaves our factory has been made with exquisite craftsmanship using state-of-the-art manufacturing techniques. The M1 PRO features outstanding aeroacoustics and advanced ergonomics. Perfected in a wind tunnel, the aerodynamics ensure stable helmet performance at all times. Naturally, the M1 PRO possesses the tried and tested SCHUBERTH helmet features you have come to expect when it comes to safety, comfort and designed. All these features, the stringent quality requirements we place on the materials used, as well as our meticulous craftsmanship, go together to make a quality product designed to meet extremely high expectations in safety and reliability on the road – especially on long journeys.

We wish you a safe ride.

A. HOW TO USE THIS MANUAL CORRECTLY

Please take time to read through this manual carefully so that your helmet protects you properly when riding your motorcycle. In order to ensure that you do not overlook any aspect of the manual that is relevant to your safety, we recommend that you read it in the order in which it appears.

Please play particular attention to:

A Caution:	safety instructions
O Note:	advice
🕑 Tip:	practical tips
Q :	see figure

A Caution:

This helmet is not intended for use in the USA and Canada. The helmet has been inspected and approved to the European ECE Standard and therefore does not conform to US and Canadian regulations and requirements. It is only legal to use the helmet in countries in which the European ECE Standard is valid. If you use the helmet in other countries, you will not in the event of injury be entitled to make a claim for compensation before the US or Canadian courts or the courts of other countries not bound by the ECE Standard.

Caution:

We reserve the right to make changes that reflect technical advances and to do so without express notice.

B. CONTENTS

A.	How to use the manual correctly	3
B.	Contents	4
C.	The helmet	6
1.	Standard	6
2.	ECE approval	6
3.	Anatomy the helmet	7
4.	Outer shell	7
5.	Inner shell	7
6.	Aerodynamics	8
7.	Aeroacoustics	8
8.	Chinstrap with Micro-Lock ratchet fastener	10
9.	Visor	11
10.	Pea	14
11.	Sun visor	15
12.	Inner lining	17
13.	Ventilation systems	19
14.	Additional safety features	20
D.	Putting on the helmet and taking it off	21
1.	Putting on the helmet	21
2.	Taking off the helmet	21
E.	Before every journey	22
1.	Checking the helmet	22
2.	Checking the chinstrap	22
3.	Checking the face shield and sun visor	23

F.	For your safety	24
1.	Safety advice concerning the helmet	24
2.	Safety advice concerning the face shield / sun visor	25
3.	Safety advice concerning modifications / accessories	26
G.	Maintenance and care	27
1.	Outer shell	27
2.	Face shield and sun visor	27
3.	Inner lining	28
4.	Ventilation	28
5.	Retention system	29
6.	Storing the helmet	29
Н.	Accessories and spare parts	30
1.	Communication systems	30
2.	Accessories and spare parts	31
3.	Ordering original SCHUBERTH parts	31

1. STANDARD

The M1 PRO conforms to the ECE-R 22.05 standard. This testing norm guarantees conformity to defined safety standards in respect of impact absorption, visor, retention system and field of vision. The certification applies to all the countries of the European Union and all countries that recognise the ECE standard. It also guarantees conformity with all insurance requirements that are important in the event of a claim.

Please note that this M1 PRO with ECE approval is not certified for the USA, Canada or any other EU countries. It is only permitted for use in countries where the ECE standard is valid.


🕐 Note:

The only SCHUBERTH helmets that it is legal to use in the USA, Canada or other non-EU countries are those with the appropriate approval and technical specifications. Further information and details of sales outlets for these helmets can be found on the internet.

2. ECE-APPROVAL



3. ANATOMY OF THE HELMET



4. OUTER SHELL

The outer shell of the M1 PRO helmet combines an aerodynamically optimal shape with consistent protection. It consists of a special glass-fibre reinforced duroplastic matrix developed by SCHUBERTH, which gives the helmet the high level of strength needed for your protection.

A Caution:

The safety helmet is designed to absorb the effects of only one impact. The helmet must be replaced after a fall, accident or any other impact.

5. INNER SHELL

For optimised impact absorption properties, the inner shell of the helmet consists of several components. The complex multi-segment foam padding of the main body provides better absorption and dissipation of impact forces and gives you the highest level of safety. The large side panels ensure the helmet sits optimally and comfortably.

6. AERODYNAMICS

Wind noise is low with the M1 PRO, both for race-riding and during long touring rides. The M1 PRO produces practically no uplift even at speed.

🕐 Note:

Please note that the strong eddy currents that can occur as a result of the fairing on faired motorcycles may have a significant effect on the aerodynamic characteristics of a helmet.

7. AEROACOUSTICS

Various features developed in SCHUBERTH's wind tunnel make the helmet notably quiet as far as aeroacoustics are concerned, while providing optimised hearing capability when riding. This enhances concentration, especially at high speeds.

🕐 Note:


Aeroacoustic values may vary according to the type of motorcycle, fairing design, seat position and physical size of the rider.

A Caution:

As a result of the aeroacoustic optimisation of the helmet (and the lower wind noise inside the helmet that comes with it), your actual speed can easily be underestimated. Please do not rely on your sense of hearing to estimate your road speed - always check it using your speedometer.

🕐 Note:

With faired motorcycles, strong eddy currents occur at the edges of the wind shadow. These may significantly reduce the aeroacoustic performance of the helmet. The motorcycle fairing should be adjusted so that the turbulence created does not reach the bottom surface of the helmet.



Turbulators

The patented turbulators on the top of the face shield also optimise the aeroacoustic properties when riding and prevent acoustic disturbances in the form of whistling sounds that can be created by smooth and straight edges.


y smooth and straight

8. CHINSTRAP WITH MICRO-LOCK RATCHET FASTENERS

The M1 PRO is fitted with a ratchet strap. This locking system is easy to use and enables you to adjust the chinstrap perfectly to your head every time you put the helmet on.

ADJUSTING THE CHINSTRAP

The length of the chinstrap is adjusted by increasing or reducing the length of strap pulled through the metal buckles. Adjust the length of the chinstrap so that it fits firmly but comfortably under your chin and fix the end of the strap using the retaining loop with comfort pad.



JUIT

A Caution:


When adjusting the strap, make sure that the helmet cannot be pulled off in a forward direction with the chinstrap closed.

A Caution:

Check the adjustment of the chinstrap length at regular intervals.

OPENING AND CLOSING

To close the chinstrap fastener, slide the ratchet tongue step by step into the locking buckle. If you find that the chinstrap fits too loosely around your chin, slide the ratchet tongue one step further into the locking buckle. When adjusting the chinstrap, make sure that it rests firmly but not uncomfortably around your chin. To open the chinstrap, pull the red ribbon on the ratchet fastener upwards to release the locking buckle. Then pull the ratchet tongue out of the locking buckle.



A Caution:

Never ride without making sure that the chinstrap is correctly fastened and adjusted and properly positioned. If the chinstrap is not correctly adjusted or fastened, the helmet could be displaced in the event of an accident.

A Caution:

Never open the chinstrap while riding.




COATING

The main visor has an anti-scratch coating.

OPENING AND CLOSING

The face shield is opened or closed by grasping one of the two finger tabs on the face shield and pushing the face shield up or down into the desired position.



REPLACING THE VISOR SHIELD

Changing the face shield is easy to do without tools using the convenient EasyChange mechanism. To replace the face shield, it is helpful to place the helmet on a flat surface or on your lap while seated.

Removing the face shield


1. Move the face shield into the uppermost locked position.

2. Press the spring underneath the face shield mechanism on one side towards the face shield opening, then do the same with the spring on the other side.

3. Move the face shield upwards until it is released from the face shield mechanism.








1. Using both hands, guide the face shields locking studs into the respective recesses in the face shield mechanism.

2. The face shield will then audibly lock into place when you press it gently towards the helmet with a simultaneous closing movement.

3. Check the function of the visor mechanism by closing the visor once and opening it as far as possible.

Safety note

Check before each journey that the face shield and sun visor mechanism are functioning correctly and that the face shield and sun visor will provide good visibility. Any dirt should be removed before setting off. Check the face shield and sun visor for physical damage and cracks. Severely scratched or scuffed face shields will seriously impair visibility and should be replaced before setting off on a journey.






A Caution:


Petrol, solvent and fuel vapours can cause cracking of the face shield. Make sure that the face shield is never exposed to such vapours! Never place the helmet on the tank of your bike.

10. PEAK




INSTALLATION

Using both hands, insert the peak into the guide of the visor mechanism and slide it down until it stops.



REMOVAL

Using light pressure, slide the peak upwards until it detaches from the visor mechanism.



11. SUN VISOR


SUN VISOR

The sun visor is scratch-resistant and uses a special polycarbonate to ensure effective protection against harmful UV radiation.

Operation

The sun visor is operated by means of the slide positioned on the left in the chin area, which is easy to use even when wearing gloves. Moving the slide towards the back lowers the sun visor, moving it forwards retracts the sun visor inside the inner helmet shell and locks it in position.

The sun visor can be operated irrespective of the position of the face shield.



O Note:

Only use the slide to operate the sun visor.

A Caution:

Never ride in the dark or in conditions of poor visibility with the sun visor down. Always raise the sun visor before entering a tunnel.

A Caution:

Riding without the face shield or with an open face shield can result in injury to the eyes and face from stones, dust, insects and other flying objects. The sun visor, when lowered, will offer a certain amount of protection from light impact from stones or insects but does not provide protection against all hazards.

REPLACING THE SUN VISOR

The sun visor can be replaced without tools.

🕑 Tip:

To avoid fingerprints and scratches, use a soft, clean cloth (we recommend a microfibre cloth) to hold the sun visor when removing or installing it.

🕑 Tip:


Changing the sun visor is easier when the chin section is open and locked in place. It is also helpful if you place the helmet on a flat surface or on your lap while seated.

O Note:

Try to prevent the sun visor coming into contact with the helmet's inner shell when removing or fitting it.

Removing the sun visor

- 1. Open and lock the chin section in place.
- 2. Pivot the sun visor down.
- **3.** Bend the middle snap connection with locating pegs gently outwards until the sun visor is released from the visor holder.
- 4. Repeat this step for the other side.




Tip:

The sun visor holders should remain in the lower position while you install the visor.

Fitting the sun visor

- 1. Put the sun visor between the snap connections and fit it on to the locating pegs on one side and then on the other.
- **2.** Position the sun visor between helmet inner and outer shell and lower it with the operating slide.
- **3.** For safety, check that the sun visor mechanism is functioning correctly.



12. INNER LINING

The interchangeable, washable and seamless inner lining of the M1 PRO ensures a secure and comfortable fit, as well as improved helmet ventilation.

The high-comfort cheek pads ensure that the helmet fits comfortably around the cheeks, and the head pad provides an optimal fit all around the head. The head pad sits comfortably on the head without covering the ventilation channels.

The internal lining consists of skin-friendly materials throughout, particularly in areas that come in contact with the head. A soft, breathable material known as Coolmax®, which is fast-drying and conducts heat efficiently is used for the padding, as well as a special anti-bacterial low-odour fabric.

REMOVING THE INNER LINING

1. Pull the neck tab from its bracket and remove the forehead padding step-by-step by opening the buttons.

2. Pull the neck padding pieces left and right from the rear, starting at the guide grooves.






3. Remove the cheek pads step-by-step by loosening the pins from the helmet shell and neck band.

INSTALLATION INNER LINING

 Pull the insertion grommets on the neck band over the pin on the cheek cushion. Using the pins, button the cheek pads onto the insertion mechanism in the helmet shell.

2. Hook the hook-shaped ends of the neck tabs behind the front screws. Then click the insertion mechanism on the neck tabs into the pins between the outer and inner shells of the helmet.



A Caution:

forehead.

Never ride when parts of the inner lining have been removed.

A Caution:

Excessive heat (e.g. exhaust heat) can cause damage to the inner lining!

🕐 Note:

To avoid damage to the inner lining and inner shell, do not hang the helmet over the mirrors or handlebar grips.

13. VENTILATION SYSTEMS

3. Insert the headband padding and begin clasping the buttons, starting from the

HEAD VENTILATION

A large adjustable ventilation regulator is placed on the top part of the helmet shell to allow for ventilation of the head's surface. The inflowing air is guided through channels along the top of the head to provide an effective supply of fresh air. The ventilation regulator can be moved back and forth to vary the among of air flowing in and thus regulating the fresh air supply. Moving the ventilation regulator to its end stop products a maximum of inflowing air.



INTERIOR AIR EXTRACTION

The helmet's innovative circulation system ensures maximum cooling and rapid dissipation of warmth in the helmet's interior. The underpressure that forms on the rear of the helmet ensures a permanent draw-off of air from the interior of the helmet to the rear of the head and neck. In this way a pleasant climate is maintained within the helmet.



14. ADDITIONAL SAFETY FEATURES

REFLECTIVE PANELS

Black reflective patches on the neck pad and forehead area make the motorcyclist more visible. With solid-colour helmets (no decals) the SCHUBERTH logo on the back of the helmet is also made of reflective film.

🕐 Note:

Keep the reflective safety areas clean.

🕐 Note:

When riding in France, local law requires that further reflective safety stickers be attached to the front, back and both sides of the helmet.

D. PUTTING THE HELMET ON AND TAKING IT OFF

🕐 Note:

Please note the information on the handling of the chin strap.

1. PUTTING ON THE HELMET

- 1. Retract the sun visor within the helmet shell.
- 2. Open the chinstrap and chinstrap comfort pad.
- 3. Pull apart the lower ends of the chinstrap.
- 4. It will now be easy to put the helmet on.
- 5. Fasten the chinstrap.
- 6. Make sure the chinstrap passes under the chin and fits snugly.

2. TAKING OFF THE HELMET

- 1. Retract the sun visor within the helmet shell
- 2. Open the chinstrap.
- 3. Grasp the ends of the chinstrap and pull the chinstrap ends apart.
- 4. The helmet can now be removed easily from the head.

🕑 Tip:

To avoid scratching any objects you might place the helmet on, we recommend closing the chin-strap after you have taken the helmet off.

E. BEFORE EVERY JOURNEY

For your safety, check the following points before every journey:

1. CHECKING THE HELMET

Check the helmet regularly for damage. Small superficial scratches will not impair the protective function of your helmet. In the case of more serious damage (cracks, dents, flaking and cracking paint, etc.), the helmet should no longer be used.

2. CHECKING THE CHINSTRAP

(WITH HELMET ON AND FASTENED)

- 1. Check that the chinstrap passes under your chin.
- 2. Slip your index finger under the chinstrap and pull.

If the chinstrap is loose under the chin, it is too long and needs to be tightened.

If the chinstrap loosens when you pull it, it is not properly fastened. Undo the chinstrap completely and try fastening it again. Repeat the test.

- **3.** If you are unable to fasten the chinstrap so that it fits snugly against the chin, check that your helmet is still the right size for you.
- 🕐 Note:

Repeat the test after each adjustment.

A Caution:

Never ride with the chinstrap unfastened or incorrectly adjusted. The chinstrap should fit correctly and should not become loose when pulled. The fastener is not correctly closed if the chinstrap becomes loose when pulled.

3. CHECKING THE FACE SHIELD AND SUN VISOR

Before every journey, check that the mechanisms of the face shield and sun visor are working properly and that the face shield and sun visor will provide sufficiently clear visibility. Any dirt should be removed before riding.

Check the face shield and sun visor for physical damage and cracks. A badly scratched face shield will considerably impair your vision and should be replaced before setting off on a journey.

A Caution:

Never use tinted face shield or sun visor in conditions of poor visibility, when riding at night or in a tunnel.

A Caution:

Stop riding if visibility is poor.

F. FOR YOUR SAFETY

1. SAFETY ADVICE CONCERNING THE HELMET

A Motorcycling is associated with particular risks and dangers for the rider and passenger. These risks and dangers can be reduced, but not eliminated completely, by wearing a helmet. It is impossible to state precisely what the protective effect of a helmet will be in the event of an accident. Safe riding techniques, adapted to the particular road and weather conditions, are essential for your safety.

A To provide adequate protection, the helmet must fit well and be securely fastened.

Always fasten the chinstrap before setting off and check that the fastening system and strap are correctly in position.

A Never ride with the chinstrap unfastened or incorrectly adjusted. The chinstrap must be correctly positioned and must not come loose when pulled. The fastener is not correctly closed if the chinstrap becomes loose when pulled.

A The full protective function of a helmet can no longer be guaranteed after an accident or impact. Like the crumple zone of a car, the impact energy of a collision is absorbed by complete or partial destruction of the structure of the outer and/or inner shell of the helmet. Because of the way helmets are designed, this damage is rarely visible from the outside. The safety helmet is designed to absorb only one impact. It is therefore essential to replace the helmet after a fall, accident or other violent impact. For safety reasons, the old helmet should be rendered unusable.

A The helmet safety mechanism described above can also cause small cracks in the shell when the helmet is dropped from a small height (less than 1 metre).

Any helmet that has been subjected to a violent impact should be replaced.

A No helmet provides absolute protection from all conceivable impacts. This helmet has been specially developed for motorcycle riding and is unsuitable for other purposes.



A Examine the helmet for damage at regular intervals. Small scratches will not impair the protective function of your helmet.



A The helmet should be replaced after 5 to 7 years, depending on use and care. Although the outer shell is in principle capable of a longer service life, the occurrence of material fatigue and wear to other components, as well as the overall action of the helmet and the unknown conditions in which the helmet has been used, make it advisable for your own safety to replace the helmet after this period of use.



A Excessive heat (e.g. exhaust heat) can cause damage to the decoration, the inner shell of the helmet and the interior lining.

A Direct contact with motor fuel, thinners or solvents can destroy the structure of the inner and outer shell. Make sure the helmet does not come into contact with such substances, even for cleaning purposes.


2. SAFETY ADVICE CONCERNING THE FACE SHIELD/ SUN VISOR

A The protective film used during shipping should be removed before use.

Any scratches and/or dirt arising from the use of the face shield and/or sun visors significantly impair your vision in any driving situation and thus increase the risk of an accident. For your own safety, replace them or clean them immediately.



A Never use a tinted face shield or sun visor in conditions of poor visibility, at night or in a tunnel!






A Make sure the face shield is always in perfect condition. Don't ride when visibility is poor!

F. FOR YOUR SAFETY

3. SAFETY ADVICE CONCERNING MODIFICATIONS/ ACCESSORIES

A Original components (in particular on the outer shell, inner shell and restraint system) should not be altered or removed. The fitting of additional parts from other manufacturers that have not been recommended can reduce the protective effect and renders the ECE certification and all warranty and insurance claims invalid.



G. MAINTENANCE AND CARE

1. OUTER SHELL

To clean the helmet shell, you can use water, soap or one of the commonly available motorcycle shampoos, cleaners, polishes, plastic cleaners or cleaning fluids. Using water and soap is usually sufficient. Make sure when using the other cleaning materials that these do not come into contact with the face shield, since they can cause damage to the visor and its coating.

Note:

Never use motor fuel, thinners or solvents to clean the helmet. These substances can cause serious damage to the helmet with no external signs. The full safety function of the helmet can then no longer be guaranteed.

2. FACE SHIELD AND SUN VISOR

OUTER SURFACE OF THE FACE SHIELD

Use a soft cloth and a mild soap solution (< $20 \,^{\circ}$ C) to remove dirt from the outside of the face shield. To dry the face shield, use a lint-free cloth and apply gentle pressure.

SUN VISOR

The sun visor should only be cleaned with a soft and, if necessary, slightly damp cloth (we recommend a microfibre cloth). Do not use any cleaning agents.

🕐 Note:

Only use tepid water (< 20 °C) for cleaning. Never on any account clean the face shield or sun visor with petrol, solvent, a window or glass cleaner or other cleaning agents containing alcohol.

O Note:

The face shield should not be soaked in water even if it is very dirty on the outside, as this will severely reduce the surface hardness and thus the durability of the anti-fog/anti-scratch coating.

G. MAINTENANCE AND CARE

O Note:

The face shield should not be completely closed when not in use (particularly during periods of storage), as the moisture contained on the inside cannot escape if closed and will largely be absorbed by the anti-fog/ anti-scratch coating. This can lead to a reduction in the lifespan of the coating.

O Note:

Never attach labels, adhesive tape or stickers to the face shield or sun visor.

🕑 Tip:

Stubborn soiling on the outside of the visor (e.g. dried-on insect residue) is easy to remove if you cover the closed visor with a damp cloth for a few minutes to soften the deposits. Repeat this procedure if required.

Note:

Always avoid temperatures above 40 °C and high humidity when choosing a place to store the face shield, as these conditions can cause damage to the face shield.

3. INNER LINING

The inner lining of the M1 PRO can be removed completely. The head and cheek pads can be washed by hand using a mild soap solution (e.g. with highly diluted standard mild detergent) at a maximum temperature of 30 °C. Allow the lining to dry at room temperature and with good ventilation.

4. VENTILATION

VENTILATION COWL

When necessary, the head ventilation system's air inlet cowl can be removed to clean the ventilation mechanism.



1. Slide the ventilation hood towards the backside of the helmet as far as possible.

2. Squeeze both sides of the ventilation hood.

2. While squeezing, slide the ventilation hood backwards out of its attachment.

5. RETENTION SYSTEM

The metal components of the retention system do not require maintenance.

6. STORING THE HELMET

Store the helmet in the helmet bag supplied in a dry, well-ventilated and stable place. Always position the helmet so that it cannot fall to the floor. Damage that occurs in this way is not covered by the warranty.

O Note:

Store the helmet out of the reach of children and animals.

H. ACCESSORIES AND SPARE PARTS

1. COMMUNICATION SYSTEMS

The helmet comes standard equipped for compatibility with the SCHUBERTH communication system — the necessary microphones, loudspeakers and cables are preinstalled, so no manual installation is necessary.

Information on the SCHUBERTH SRC System $^{\rm TM}$ and SC1M is available from specialised dealers.



A Caution:

The installation of a communication system (including basic headsets) constitutes a modification to the helmet. For this reason it is necessary for any communication system and headset intended for installation into a specific model of helmet to be tested and approved in line with the ECE-R 22.05 European helmet standard, otherwise the helmet's approval and compliance with insurance requirements become invalid on installation.

Evidence of approval in line with ECE-R 22.05 in connection with a specific communication system is only valid if certified by an official regulatory office of an EU member state. Any other form of information from these or other institutions (e.g. on the general suitability of communication systems for use in motorcycle helmets) is of no relevance and the helmet will lose its approval.

2. ACCESSORIES AND SPARE PARTS

An overview of all available accessories and spare parts can be found on the Internet.

We recommend that you only use original SCHUBERTH accessories and spare parts for your SCHUBERTH helmet as they are specially adapted to your helmet model.

A Caution:

For safety reasons, all other parts of the helmet should only be replaced by your specialist dealer.

3. ORDERING ORIGINAL SCHUBERTH PARTS

Please contact your specialist dealer for original SCHUBERTH accessories and replacements.