



Installation Instructions
Part 15373-426
GL1500 Chrome Carb Covers

NOTE: Read Instructions Carefully Before Installing

1. Place motorcycle on the center stand.
2. Remove the left and right side covers by pulling at the rear of the cover.
3. Unscrew the upper side cover from the bottom side covers
4. Install the new chrome cover replacement

NOTE: Put a small amount of oil on the grommets. Reinstall the side cover.



Installation Instructions
Part 15373-426
GL1500 Chrome Carb Covers

NOTE: Read Instructions Carefully Before Installing

1. Place motorcycle on the center stand.
2. Remove the left and right side covers by pulling at the rear of the cover.
3. Unscrew the upper side cover from the bottom side covers
4. Install the new chrome cover replacement

NOTE: Put a small amount of oil on the grommets. Reinstall the side cover.

