



**18673-818K
GL1800 ARMREST
Mounting Instructions**

**Read instructions fully before installing armrests.
MUST HAVE TWO ANTENNAS TO MOUNT ARMRESTS.**

1. Place bike on center stand.
2. Remove the two screws on each antenna.
3. Holding the chrome adaptor vertical, slip the armrest bracket between the adaptor and the antenna.
4. Insert the longer bolts and washers and tighten the screws.
5. Reattach each antenna.

AFTER INSTALLATION:

1. Drill a ¼ inch hole in the pocket through the hole in the pivot arm.
2. Install one spacer between the pivot arm and pocket.
3. Insert the chrome bolt through the pivot arm and spacer.
4. Place the other spacer, fender washer spacer and lock nut inside the pocket. Tighten.
Do Not Over Tighten.

NOTE: Do not use the armrest when mounting the motorcycle.

