



**MOUNTING INSTRUCTION FOR
GL1800 2012 Chrome Side Windshield Panel Accent
PART NUMBER 45-1294**

Note: Read instruction thoroughly before installing.

1. Clean area thoroughly with alcohol pads provided.
2. Place each chrome accent on the windshield panel to check fitment. The accents should fit along curves of the windshield garnish.
3. Remove cover over two sided tape.
4. Attach each chrome accent separately and press on firmly for 2 minutes.
5. Do not ride bike for 24 hour to insure secure hold for adhesive tape.

