



MOUNTING INSTRUCTION FOR GL1800 2012 Chrome Headlight Side Trims PART NUMBER 45-1298

Note: Read instruction thoroughly before installing.

1. Place bike on center stand.
2. Clean each area thoroughly with alcohol pads provided.
3. Place each chrome accent on each side to check fitment.
4. Remove cover over two sided tape. Figure 1. Work one side at a time.
5. Attach chrome accent and press on firmly for 2 minutes.
6. Do not ride bike for 24 hour to insure secure hold for adhesive tape.



Figure 1

