



MOUNTING INSTRUCTIONS
For 45-1299 -GL1800 Chrome Headlight Cover Trims
2012 Model Only

NOTE: Read instructions thoroughly before installing. Work one side at a time.

- 1. Place bike on center stand.**
- 2. Thoroughly clean outside surface where the cover trim is to be mounted with rubbing alcohol pads provided.**
- 3. Check fitment of the piece.**
- 4. Remove tape backing on chrome accent.**
- 5. Press the accent into place. Hold firmly for 1 minute.**
- 7. Repeat on the other side.**
- 8. Wait at least 6 hours riding.**

