



# INSTALLATION INSTRUCTIONS

## for PART 45-1629NUA

### GL1800 01-10 Air Intake Predator Grills

Read instructions thoroughly before installation.

1. Place bike on center stand.
2. Clean area thoroughly with alcohol pad provided.
3. Each Predator Grill© should have positioning marks at the end of each piece.



L bottom for Left Bottom  
 R bottom for Right Bottom  
 L top for Left Top  
 R top for Right Top

Left Top      Left Bottom      Right Top      Right Bottom

4. Position grills on fairing intake grill center bar where desired.



45-1629NUA Left Side



45-1629NUA

- 4A. On Add On part 45-1629NUB, Chrome Side fairing Accents with Mesh Inserts, the Predator Grills©'s tab will guide the positioning of the grill in the openings of the chrome mesh insert.



Tab      Left Side      Tab

Tab      Tab



Tab      RIGHT SIDE      Tab

Tab      Tab

5. When positioning is complete, use the silicone provided to attach each Predator Grill©. Run a bead of silicone on the flat side of each grill. Work with one grill segment at a time. Carefully place each grill into position. Clean up any excess silicone. Using wire ties provided, secure Predator Grills© in place. Let grills set for 24 hours. Remove wire ties after drying.

