



MOUNTING INSTRUCTIONS FOR
Part 45-1804
GL1800 01-10 CHROME SADDLEBAG SCUFF PLATE

Read instructions thoroughly before installing.

1. Remove the left or right engine side plate cover from bike.
2. Remove the three screws that hold the original black scuff cover on to the engine side plate cover.
3. Place the new chrome scuff cover in position and screw on to the side plate cover. Tighten screws evenly. Do Not Over Tighten. Repeat other side.
4. Replace the engine side plate covers on to bike.

NOTE: Do Not Remove the film from the double sided tape. It will be used as a pad and not for mounting the plates.

