



**MOUNTING INSTRUCTION FOR  
GL1800 2012 Chrome Taillight/Turnsignal Grills 3 Piece  
PART NUMBER 45-1897**

**Note: Read instruction thoroughly before installing.**

1. Clean area thoroughly with alcohol pad provided.
2. Place each chrome grill on turnsignal and tail light to check fitment.
3. Remove cover over two sided tape.
4. Attach each chrome grill separately and press on firmly for 2 minutes.
5. Do not ride bike for 24 hour to insure secure hold for adhesive tape.

