



**MOUNTING INSTRUCTION FOR  
GL1800 2012 Chrome Saddlebag Scuff Cover Inserts  
PART NUMBER 45-1898**

**Note: Read instruction thoroughly before installing. No hardware is needed to install inserts.**

1. Place bike on center stand.
2. Working one side at a time, place insert in opening.
3. Gently push insert into opening in saddlebag scuff cover until you hear it snap in.
4. Repeat on other side.

