



INSTALLATION INSTRUCTIONS FOR
Part 45-8943
GL1500 LED LIGHTED LICENSE FILLER ACCENT

Read instructions thoroughly before installing

1. Remove license plate and frame. On 98 newer models, remove the stock chrome filler.
2. On the back of the lighted filler, observe the location of the adhesive strips. Temporarily slide the lighted filler into position on the motorcycle to determine approximately where the adhesive will contact the painted surface on the bike. Thoroughly clean this area with glass cleaner and allow area to dry.
3. Remove the bottom cover of the trunk (secured with 4 Phillips screws). Find the wires leading to the trunk mounting tail light. With your test light, find the wire for tail and stop lamps and label or mark them.
4. Run the wires up the right side of the back of the filler so they exit from behind the top of the part when installed. Remove the adhesive backing from the strips on the lighted filler. Set the filler into position. The bottom of the chrome filler should line up with the top of the red plastic lens. Apply pressure, for about 30 seconds, to insure a good bond.
5. Replace the license plate.
6. Snap the red quick splices on to the tail and stop lamps wires you labeled earlier (under the travel trunk). Crimp the ring terminal on the black wire from the lighted filler.
7. **CONNECTIONS:** Black- Chassis ground
Red- Running or tail lights
White- Stop light

The shrouded male spade connectors simply plug into the “tab” ends of the quick splice connectors.

8. Replace the bottom cover of the travel trunk.

NOTE: In regards to the locating pins you can either drill holes or cut them off.

