



**MOUNTING INSTRUCTION FOR
CanAm® Chrome Handlebar Top Cover
PART NUMBER 46-1000**

Note: Read instruction thoroughly before installing.

1. Clean area thoroughly with alcohol pad provided.
2. Place top cover over handlebar to check fitment.
3. Remove cover over two sided tape.
4. Attach chrome cover and press on firmly for 2 minutes. Or use silicone provided for permanent attachment.
5. Do not ride bike for 24 hour to insure secure hold for adhesive.

