



Instructions for Part 673-165A GL1200 ASP Handlebar Cover

Read Instructions carefully before installing.

- 1.** Unfasten black OEM handlebar clamp cover by removing the two Phillips head screws at the lower bottom edge. Slide the cover up over the key switch.
- 2.** Remove the trip computer head by unfastening the four screws attaching it to the back of the cover. Remove the small cover by prying the two spring clips off the back of the cover. Install both these units onto the chrome replacement cover reusing the OEM hardware.
- 3.** Reinstall onto motorcycle using screws removed in step 1. Make certain the forward edge of the chrome replacement cover engages retainer clips before tightening screws.

