



## Instructions for Part 673-823

### GL1200 84-87 Saddlebag Light Kit

Read instructions thoroughly before starting installation.

NOTE: Three lights are required to replace the two side saddlebag and the rear reflectors in order to turn them into lights.

1. Remove reflectors from the bike. Rear and/or two side on the saddlebag.
2. Remove the rubber boot from the light kit.
3. Use the template to determine light placement and outline cut out area. Note: Light is not centered on light panel.
4. Cut into saddlebag and/or rear reflector areas as measured above.
5. Use silicone glue on cut edges of the cut out.
6. Slide rubber boot into opening from the inside of the saddlebag and from the rear underside of the bike.
7. Install light, threading wires first.
8. Thread wires to tail light and splice into running side of the tail light.

