



INSTALLATION INSTRUCTION FOR FLUSH MOUNT AXLES  
FA0001 THROUGH FA0006

- 1) RAISE BIKE FRONT END UNTIL TIRE IS ¼" OFF THE GROUND.
- 2) REMOVE THE FRONT AXLE.
- 3) INSERT THE NEW THREADED FLUSH **NUT CAP** UP TO THE KNURL IN THE LOWER LEG.
- 4) INSERT NEW AXLE, USING ½" DRIVE RATCHET AND 9/16 SOCKET. TIGHTEN UNTIL **NUT CAP** IS FLUSH WITH LOWER LEG.
- 5) SINCE YOU ARE TIGHTENING THE AXLE INSTEAD OF THE NUT, YOU WILL NEED TO CHECK THE POSITION OF THE SPEEDOMETER GEAR.
- 6) USING A TORQUE WRENCH AND A 9/16 SOCKET, TIGHTEN THE AXLE TO 55 FOOT POUNDS.
- 7) PLACE THE FLUSH MOUNT HEX COVER **END CAP** IN THE PINCH CAP SIDE, HOLDING IT FLUSH IN PLACE, TIGHTEN THE PINCH CAP.