



INSTALLATION INSTRUCTIONS FOR ADJURE LAMPS

MOTORCYCLES WITH HEAD OR SPOTLIGHT BUCKETS:

ADJURE'S HEAD & SPOTLAMPS ARE A DIRECT REPLACEMENT FOR MOST MOTORCYCLES. TO INSTALL SIMPLY REMOVE YOUR OLD LAMP AND REPLACE WITH YOUR NEW ADJURE LAMP, EXCEPT AS DESCRIBED BELOW. MOST METRIC MOTORCYCLES ARE DESIGNED AND BUILT SO THAT YOU MUST BUY MOST OR ALL ASSY'S FROM THE MANUFACTURER. WE DO OFFER AN ADAPTOR RING TO MAKE OUR 7" HEADLAMPS FIT INTO 96 TO 02 KAWASAKI VULCAN, 98 TO 02 NOMAD'S AND HONDA'S 95 TO 02 ACE MODELS. THE PART NUMBER IS
T70RG-A.

MOTORCYCLES WITH NACELLES OR FAIRINGS:

WAVE & FLUTE CUT 7" LAMPS:

AFTER REMOVING YOUR OLD LAMP REMOVE THE ADJUSTER PLATE BY UNHOOKING THE SPRING OUT OF THE PLATE AND SLIDING THE PLATE OUT OF THE 2 ADJUSTING SCREWS. REMOVE THE RUBBER BOOT FROM THE BACK OF THE LAMP. SET THE LAMP INTO THE ADJUSTER PLATE (MAKING SURE THE LAMP FITS INTO THE LOCATORS) AND REPLACE THE BOOT FROM THE BACK SIDE. PUT ALL BACK TOGETHER STEP BY STEP THE OPPOSITE WAY YOU TOOK IT APART.

DIAMOND CUT 7" LAMPS:

AFTER REMOVING YOUR OLD LAMP REMOVE THE ADJUSTER PLATE BY UNHOOKING THE SPRING FROM THE PLATE, AND SLIDING THE PLATE OUT OF THE 2 ADJUSTING SCREWS. THE HOLE IN THE BACK OF THE ADJUSTER PLATE (ON PRODUCTION MC'S) IS 20 THOUSANDS SMALLER THAN THE BACK OF THE LAMP. YOU CAN EASILY TRIM THE HOLE WITH A FILE. OR YOU CAN BUY A PLATE FROM US WITH A LARGER HOLE P/N# T70RG-B. THEN REMOVE THE RUBBER BOOT FROM THE BACK OF THE LAMP. SET THE LAMP INTO THE ADJUSTER PLATE (MAKING SURE THE LAMP FITS INTO THE LOCATORS) AND REPLACE THE BOOT FROM THE BACK SIDE. PUT ALL BACK TOGETHER STEP BY STEP THE OPOSITE WAY YOU TOOK IT APART.

USING THE H-D FRENCHED (BEZEL) TRIM RING:

AFTER INSTALLING THE 7" LAMP PER THE INSTRUCTIONS ABOVE. YOU MAY HAVE A GAP BETWEEN THE LAMP AND THE BEZEL. TO ELIMINATE THIS GAP YOU MUST RAISE THE ADJUSTER PLATE. WE HAVE INCLUDED A NYLON DOWEL TO DO THIS. THE DOWEL FITS INTO THE MIDDLE OF THE ADJUSTER PLATE SPRING AND UNDER THE TOP LIP OF THE PLATE.

- 1- MEASURE THE GAP & REMOVE THE BEZEL.
- 2- MEASURE THE DISTANCE BETWEEN THE BOTTOM OF THE SPRING AND THE LIP OF THE ADJUSTER PLATE.
- 3- CUT THE DOWEL TO SIZE: EXAMPLE: GAP= $\frac{1}{4}$ ", ADJUSTER PLATE= $2\frac{1}{4}$ " = $2\frac{1}{2}$ ".
- 4- UNHOOK THE SPRING FROM THE ADJUSTER PLATE.
- 5- RAISE THE PLATE ENOUGH TO SET THE DOWEL INSIDE THE SPRING AND UNDER THE LIP OF THE PLATE. YOU WILL HAVE TO LOOSEN THE ADJUSTING SCREWS TO DO THIS.
- 6- HOOK THE SPRING INTO THE ADJUSTER PLATE AND INSTALL THE BEZEL.
- 7- ADJUST THE HEADLIGHT FIELD OF VIEW.