



## RETRO FORK BOOT SET FOR 1986-UP FLT/FLST MODELS

Thank you for purchasing this Arlen Ness product. We believe that our products are the very best available and are engineered to provide a lifetime of use. Our retro fork boot set offers a radical new custom look to your motorcycle. Basic hand tools and a service manual applicable to your model of motorcycle are all that is necessary to complete the installation.

Part #	Quantity	Description	BILL OF MATERIALS
Varies by kit	2	Retro accordion fork boot for 1986-UP FLT/FLST	
H-002	1	Loctite removeable threadlocker	
H-368Z	4	1/4" lock washer, zinc	
H-555Z	4	1/4 -20 x 3/4" hex head cap screw, zinc	

**MAINTENANCE TIP:** To keep your new fork boots looking their best, we recommend applying a high-quality chrome polish to them every time you detail your motorcycle.

**STEP 1:** Following the procedures listed in the appropriate service manual for your year and model of motorcycle, remove the existing lower fork boots from your motorcycle. This is a good time to check the wear on your brake pads and rotor(s), front wheel bearings and other basic maintenance items.

**STEP 2:** Following the procedures listed in the appropriate service manual for your year and model of motorcycle, install your new Ness Retro fork boots using the supplied hardware. Prior to riding, ensure proper clearance between the fork boots and fender.