



FIG. 1 Guage Bezel



FROM THE TOOLBOX

Flathead screw driver
Terry or microfiber cloth

IMPORTANT NOTE*

The Assault Industries bezel is designed with very tight tolerances so that it will not pop off of the OEM guage. Removal is not possible without destroying it. Proper alignment is critical as once the Assault Industries bezel is applied, it will be very difficult to rotate or remove.

INSTALLATION

1. Wrap head of flathead screwdriver with cloth.
2. Place cloth-wrapped screwdriver head under the plastic OEM bezel and carefully pry it away from the dashboard.
3. *Align Assault Industries aluminum bezel (Fig. 1) so that it is centered properly over the OEM speedometer.
4. Press bezel firmly into place.
5. Admire your work.