

BAK-UP USA

INSTALLATION GUIDE

BMW K1600GT DRIVER'S BACKREST

1. Remove the driver's seat.
2. Locate and remove the (2) two torx head screws that attaches the pillion to the bike.
3. Place the backrest in position correctly aligning the bracket feet to the screw holes.
4. Re-install the screws and tighten.
5. Re-install the driver's seat. Adjust your backrest to your preference.

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**