

Copyright © 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

INSTALLATION INSTRUCTIONS

NECK COVERS

FITS SUZUKI

PART NO. 82-201

C50/M50 2005-08, VL800 2001-04

Revised 02/10/09

TOOLS NEEDED: 6MM ALLEN WRENCH
12MM WRENCH

NOTE: TWO PEOPLE ARE NEEDED FOR INSTALLATION OF THIS PART. THE SEAT NEEDS TO BE REMOVED AND THE TANK PULLED BACK TO INSTALL THIS PART.

1. USING A 6MM ALLEN WRENCH, REMOVE THE PASSENGER SEAT AND THE DRIVER SEAT.
2. USING A 12MM WRENCH, REMOVE THE BOLT AT THE BASE OF THE TANK THAT HOLDS THE TANK ON. NOW PULL THE TANK BACK TO ACCESS THE NECK COVERS. HAVE THE OTHER PERSON HOLD THE TANK SO IT DOESN'T FALL.
3. REMOVE THE OEM NECK COVERS. THERE ARE BOSSES THAT GO INTO RUBBER GROMMETS ON THE TOP AND THE SIDE OF EACH HALF OF THE NECK COVERS.
4. INSTALL THE RUBBER FOAM PIECES PROVIDED ON EACH SIDE OF THE NEW NECK COVERS ON THE LOWER PART OF THEM, SAME AS OEM.
5. INSTALL THE NEW NECK COVERS BY HOLDING EACH HALF AROUND THE FRAME. ALIGN THE ALIGNMENT TABS ON THE TOP OF THE LEFT SIDE COVER INTO THE SLOT ON THE RIGHT SIDE COVER, THEN SEAT THE TOP BOSSES INTO THE GROMMETS AND PUSH EACH OF THE SIDE BOSSES INTO THE SIDE GROMMETS.
6. REINSTALL THE TANK AND SEAT IN THE REVERSE OF REMOVAL.