

COBRA

Items Supplied >

- 1 - Freeway Bar
- 2 - 6mm x 70mm Bolts
- 2 - Spacers
- 2 - 6mm Flat Washers

Application >

VULCAN 1500D/E/N 96-08

Instruction Manual >

01-1431

Page 1 of 1

1. Remove the two bolts that attach the horn bracket to the frame.
2. Place the supplied spacer tubes over the small tubes that the horn bracket bolts came out of.
3. Remove the front floorboard mount bolt on each side of your motorcycle. Mount the bottom Freeway Bar brackets to this location using the stock bolts. Torque to factory specification.
4. Mount the top Freeway Bar brackets using the supplied hardware. The horn and horn bracket will remain in its original position.

Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.