

Items Supplied >

- 1 Sissy Bar Rack
- 4 M8 x 20 mm Buttonhead Bolts

Application(s) >

Suzuki Boulevard M109R 06-09 Suzuki Boulevard M90 2009

Instruction Manual >

02-3605

- 1. Working on the right hand side of the motorcycle, remove the two bolts, which secure the sissy bar to the support bracket. The stock bolts will not be used for reassembly.
- 2. Carefully slide the sissy bar rack between the support bracket and sissy bar, aligning the holes.
- 3. Install the new supplied M8 x 20 mm bolt and finger tighten.
- 4. Repeat steps 1 through 3 on the left hand side of the motorcycle.
- 5. Tighten bolts to 16 ft. lbs.
 - * Cobra sissy bar racks are designed to fit with Cobra sissy bars only *
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

Anything's Possible.

11/08