



Items Supplied >

- 1 – FORMED RACK
- 2 – LONG SPACERS
- 2 – SHORT SPACERS
- 4 – M8 x 50mm BUTTONHEAD BOLTS

Application(s) >

YAMAHA RAIDER

2008-2015

Instruction Manual >

02- 4265

Your formed rack will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new rack.

1. Remove the front left and right M8 bolts from both fender rails and discard.
2. Install your new rack by inserting (2) of the supplied M8 x 50 mm buttonhead bolts through the front rack mounting holes, (2) supplied short chrome spacers, fender rail holes and into frame. Snug bolts with rack slightly elevated in the rear to access the rear fender rail bolts.
3. Remove the (2) M8 rear fender bolts and discard. Place the (2) long chrome spacers in fender rails and lower the rear of rack until holes line up. Insert the (2) remaining M8 x 50mm buttonhead bolts through rack, spacers, fender rails and into frame. Check rack for proper alignment and torque all (4) bolts to their factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
12/08

Anything's Possible.®

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.