



### Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 4 – M10 x 40 mm SS Buttonhead Bolts

### Application(s) >

HONDA SPIRIT 750 C2	07-09, 12-14
HONDA PHANTOM 750	2010-2015

### Instruction Manual >

02-6111

**Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove your stock fender rail bolts.
2. Install your Cobra saddlebag supports using the supplied M10 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
3. Torque bolts to factory specifications.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
11/08

***Anything's Possible.®***

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.