

COBRA

Items Supplied >

- 1 - Left Saddlebag Support
- 1 - Right Saddlebag Support
- 2 - M10 Spacers

Application(s) >

Honda ACE 750 98-03

Instruction Manual >

02-6115

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts.
2. Place the supplied spacers in the front recessed holes on the fender rails.
3. Install your Cobra saddlebag supports using the stock bolts (where the stock bolts were removed). The saddlebags should hang towards the rear and away from the motorcycle.
4. Torque bolts to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

07/03

Anything's Possible.

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.