

## Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support

## Application(s) >

Yamaha V-Star 650 98-10

## Instruction Manual >

02-6201

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- 1. Remove your stock fender rail bolts on the right side of the motorcycle.
- Install your Cobra saddlebag supports using the stock bolts into the countersunk portion of your fender rails (where the stock bolts were removed). The saddlebag supports should have the angled portion towards the rear of the motorcycle on each side. Tighten the bolts loosely and repeat on opposite side.
- 3. Torque bolts to factory specifications.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

AAAAAA

Anything's Possible.