

Items Supplied >

- 1 Plated LH Saddlebag Support
- 1 Plated RH Saddlebag Support

Application(s) >

KAWASAKI VN1500P KAWASAKI VN1600A KAWASAKI VN1600B SUZUKI MARAUDER 1600

Instruction Manual >

02-6461

- 1. Remove the bolts from left side of rear fender but do not discard hardware.
- 2. Install the left side Cobra saddlebag rail using the stock hardware removed in step 1.
- 3. Repeat steps 1 thru 2 for right side of vehicle.
- 4. Check alignment of fender then torque fender bolts to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019REV. A

Anything's Possible.

03/02