



Items Supplied >

- 1 – Set Of Plated Saddle Bag Supports
- 2 – M8 x 30mm Button Head Bolts
- 2 – M8 x 35mm Button Head Bolts
- 2 – Spacer, Short .200" Short
- 2 – Spacer, Long .500" Long

Application(s) >

Kawasaki VN900 06-15

Instruction Manual >

02-6468

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts on left side.
2. Place the supplied spacers and stock fender isolator bushings in the recessed holes on the fender rails (large spacer to the front, small spacer to the rear.)
3. Install your Cobra saddlebag supports using the supplied button head bolts (where the stock bolts were removed) the saddlebag supports should hang towards the rear and away from the motorcycle. Repeat on right side.
4. Torque bolts to factory specifications.

Note: If using Cobra sissy bar mount the saddlebag supports over the sissy bar brackets and do not use supplied spacers.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.