

COBRA

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 25mm Button Head Bolts
- 4 - 8mm x 20mm Button Head Bolts

Application(s) >

- ACE 1100 95-99
- ACE Tourer 98-01
- VT1100 Shadow 87-96
- VT1100 Spirit 97-07
- VT1100 Sabre 00-07

Instruction Manual >

02-7635 / 02-8635

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the two (2) rear bolts on each fender rail first on the right side.
2. Install the brackets on the outside of the fender rail with the bent portion of the bracket facing towards the inside (part number) using the supplied M8 x 25 mm bolts. Repeat on the left side
3. Install the sissy bar to the brackets using the M8 x 20 mm bolts. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

07/08

Anything's Possible.

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.