

Items Supplied >

- 1 Sissy Bar w/pad
- 2 Brackets
- 4 Spacers
- 4 M10 x 50mm Buttonhead Bolts
- 4 M8 x 20mm Buttonhead Bolts

Application(s) >

HONDA SPIRIT 750 C2 HONDA PHANTOM 750 07-09, 12-14 2010-2014

Instruction Manual >

02-8611B

Read all instructions carefully and completely before installing your new sissy bar.

- Remove the stock fender rail bolts one side at a time.
- 2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely.
- 3. Install the sissy bar to the brackets using the four (4) supplied M8 x 20mm Button Head bolts then tighten all hardware.

To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green. Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.

*Cobra®recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 03/10 REV. A

Anything's Possible.

Looking for dependable motorcycle luggage rack & support? Rely on Cobra USA for quality and long-lasting products.