

# COBRA

## Items Supplied >

- 1 - 20" Wire with Push On Connector
- 1 - Push On Connector
- 1 - Blue Quick Splice Connector
- 2 - Aluminum Turn Signal Adapters
- 2 - 1/4"-20 x 3/8" Button Head Bolts
- 3 - Cable Ties

## Application(s) >

YAMAHA V-STAR 1100 CLASSIC 99-09

## Instruction Manual >

04-0241

Page 1 of 1

**Read your installation instructions completely before beginning. This light bar can be installed in just a few minutes using common tools. It is recommended however, that a qualified mechanic or technician install this product.**

1. Your Boulevard Light Bar comes with everything you need to mount and wire it to your motorcycle. After unpacking the light bar, you will need to turn the spot lights around 180 degrees. They are facing backwards for packaging purposes only.
2. Remove your headlight bulb assembly and unplug your turn signals and remove them from their original mounts, make sure to save the screws. Mount the turn signals to the aluminum fittings underneath the light bar using the stock turn signal and screws. Remove the original turn signal mount bar and set it aside.
3. Install your light bar on the lower triple tree using original hardware. Align the assembly and tighten the two bolts to factory torque specifications. Align the turn signals and spotlights and make sure the screws on top of the light bar that hold the turn signal adapters are snug.
4. Twist the ends of the two spotlights together and insert them into the supplied push on connector and crimp with a wire crimp tool. Connect this wire to one pole on your light bar switch. It doesn't matter which one. Refer to the Yamaha wiring diagram to determine which wire is the blue front running light wire. Feed the wire from the light bar switch through the back of the headlight housing. Attach the wire from the switch to your blue running light wire using the blue quick splice connector supplied.
5. Plug your turn signal wires back into their original location. Reinstall the headlight bulb assembly back into its housing with the two (2) Phillips screws. Route the wiring behind the light bar.
6. **Check to make sure that your handlebars turn lock to lock without any stretching or binding of any wires.** Check the alignment of all of your lighting. Make sure everything is working properly before riding.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*