

# COBRA

## Items Supplied >

- 1 - Light Bar Assembly
- 2 - 6mm Flat Washers
- 2 - 6mm Nylock Nuts
- 2 - 6mm x 40mm Bolts
- 1 - Ground Wire

## Application(s) >

- KAWASAKI VULCAN 800B 95-05
- KAWASAKI VULCAN 1500D/E 96-04

## Instruction Manual >

04-0431

Page 1 of 2

**Read your installation instructions completely before beginning. It is recommended however, that a qualified mechanic or technician install this product.**

1. After unpacking the light bar, you will need to turn the spotlights around 180 degrees. The wire coming from each spotlight should both mount to one of the push on terminals on your light bar switch (it doesn't matter which one). Take the other wire supplied and mount it to the other terminal on the switch. This is the wire that will supply the power.
2. Support the motorcycle to take the weight off the front of the motorcycle to ease triple clamp removal and installation. Raise the top triple clamp by removing the 27mm bolt in the center and loosening both hex bolts at each fork leg. Slip it just past the top of the fork tubes. You can leave the handlebar and all the hardware on the triple clamp.
3. Slide the chrome fork tube covers up to clear the turn signals and remove the turn signal assemblies. Reinstall the chrome fork tube covers and upper triple clamp.
4. Remove the headlight assembly and housing.
5. Install the light bar and headlight housing using the supplied nuts, bolts, and washers. The light bar always mounts under the headlight bracket (and windshield brackets if using with a windshield).
6. Re-route and connect the turn signal wires into their original location. Test the turn signals to make sure they work properly. NOTE: The turn signal is always brighter than the running light. If they do not work, try reversing the gray and blue wires and test again.
7. Route the light bar wire the same path as the right turn signal wires are routed. Connect the wire from the light bar switch to your running light wire (see chart below) using the supplied blue quick splice clip. Attach the short ground wire under the lower triple clamps with one end on the bolt that holds the headlight mount and the other end on the screw which secures the fork covers.
8. Reinstall the headlight. Check to make sure your handlebars turn lock to lock without any stretching or binding of any wires. Check the alignment of all your lighting. Make sure everything is working properly before riding.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

**Anything's Possible.**

## WIRING CHART

### VULCAN 800 CLASSIC

<u>Wires</u>	<u>Application</u>
BLK/YEL	Ground
BLUE	Running Light
GRAY	Right Turn Signal
GREEN	Left Turn Signal

### VULCAN 1500 CLASSIC

<u>Wires</u>	<u>Application</u>
BLK/YEL	Ground
RED/BLUE	Running Light
GRAY	Right Turn Signal
GREEN	Left Turn Signal