

# COBRA

## Items Supplied >

- 2 – Cable Ties
- 1 – Drive Shaft Cover

## Application(s) >

- VTX1800C/R/S 02-UP
- VTX1300C/S 02-UP
- VTX1800N 04-UP
- VTX1800F 05-UP

## Instruction Manual >

06-0650

**Before installing your Cobra Drive Shaft cover read all instructions carefully**

1. Place the cable ties through the tabs on the backside of the drive shaft cover.
2. Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the motorcycle.
3. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not interfere with the tire.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***