

COBRA®

Items Supplied >

CHROME DRIVE BELT GUARD

Application(s) >

YAMAHA RAIDER

2008-2014

Instruction Manual >

06-0765

Your Drive Belt Guard will install in minutes using common tools. Read instructions carefully and completely before installing your new Cobra product.

1. Remove stock drive belt guard and retain bolts for use in the installation.
2. Align Cobra drive belt guard so the holes line up with the stock mounting locations and using the stock bolts retained in Step 1 begin threading until snug. **Do not tighten.**
3. Adjust the drive belt guard so that it does not make contact with the belt or any other components. After reaching the desired position fully tighten the bolts to their factory specifications.

**Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible®