



### Items Supplied >

- 1 – DRIVE BELT GUARD
- 1 – SPACER
- 1 – 6mm x 12mm BUTTONHEAD BOLT
- 1 – 6mm x 20mm BUTTONHEAD BOLT

### Application(s) >

YAMAHA STRYKER

2011-2014

### Instruction Manual >

06-0770

**Your drive belt guard will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new drive belt guard.**

1. Remove the hardware securing the stock belt guard and discard.
2. Install your belt guard by inserting the supplied 6mm x 20mm bolt into the front mounting hole of the belt guard, through the spacer and into the swingarm where the stock front bolt was removed.
3. Insert the 6mm x 12mm bolt through the rear mounting hole of the belt guard and into the swingarm where the stock rear lower bolt was removed. Tighten all bolts to their appropriate values.

***\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

***Anything's Possible.®***