

# COBRA®

## Items Supplied >

1 – SWING ARM COVER

## Application(s) >

Suzuki Boulevard M109 06-14

## Instruction Manual >

06-0846

1. Remove the 6mm hex head bolt and brake line retaining clip from the lower rear edge of the swing arm.
2. Thoroughly clean the outside surface of the swing arm, removing any oil or residue where the swing arm cover will be attached.
3. Peel the backing off of the two sided high bond adhesive strips and carefully place the swing arm cover into position on the swing arm. Replace the 6mm hex head bolt and brake line retaining clip.
4. Press firmly on the swing arm cover for one minute. **Do not pull on the cover to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.®***