

COBRA

Items Supplied >

- 1 - Set Floorboards with Mounts
- 1 - M8 x 45mm Hex Bolt
- 1 - M8 Nylock Nut
- 1 - M10 x 100mm Hex Bolt
- 1 - Spacer
- 2 - Washer Flat 5/16

Application(s) >

HONDA VT1100 SPIRIT 97-UP

Instruction Manual >

06-1621

Page 1 of 1

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove your right side foot peg from the motorcycle. Remove the lower left 10mm bolt from the stock foot peg mount bracket. Loosen upper right bolt ½ turn.
2. Locate your right side Cobra floorboard assembly (the one with the square post that is welded on the back side at a slight angle). Note how the floorboard is assembled. This is very important because you will have to reassemble it later in these instructions. Disassemble the **RIGHT SIDE FLOORBOARD ONLY** from the mounting bracket.
3. Install the mounting bracket in the stock foot peg mount socket using the supplied M8 x 45mm hex bolt, two flat washers and nut. Do not tighten the bolt. Install the M10 x 100mm hex bolt through the mounting bracket, supplied spacer and through the brake lever pivot and into the threaded frame boss.
4. Tighten all bolts. Now reinstall the Cobra floorboard to the floorboard mount. Make sure to bend one leg of the cotter pin after installation.
5. Remove the gearshift lever from the left side of the motorcycle. Remove the stock foot peg mounting bracket. Install the complete Cobra floorboard and mount assembly in place of the stock foot peg mount. Reinstall the shift lever.
6. Tighten all bolts to factory torque specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.