

COBRA

Items Supplied >

- 1 – Set Of Mounts With Floorboards
- 4 – 8mm x 35mm Bolts
- 4 – Flat Washers
- 4 – Spring Washers
- 4 – Black Spacers

Application(s) >

- ACE 95-99
- ACE TOURER 98-01

Instruction Manual >

06-1630/06-4130

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installation

1. Remove your original foot peg mounts from the frame.
2. Place the provided spacers in between your Cobra mounts and your frame. Bolt mounts to the frame using the supplied hardware.
3. Tighten bolts to factory torque specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.