

# COBRA

## Items Supplied >

- 1 – Left Floorboard Assembly
- 1 – Right Floorboard Assembly
- 2 – 8mm x 40mm Hex Bolts
- 2 – 8mm Hex Nuts

## Application(s) >

Suzuki Volusia 800 01-04  
Suzuki Boulevard M50 05-14

## Instruction Manual >

06-1825/06-4325

**This product installation may require adjusting the brake pedal and gear shifter. Read all instructions carefully and completely before installing your new Boulevard Products Floor Boards.**

1. Remove the stock front foot pegs.
2. Install the Cobra left side floorboard using the supplied 8mm x 40mm bolt and 8mm nut.
3. Repeat step (2) for right side.
4. Check the rear brake assembly & pedal to make sure it is in good working order and does not interfere with floorboard. Note: The rear brake should be checked before every ride.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

***Anything's Possible.®***