

COBRA®

Items Supplied >

- 1 – Left Floorboard Assembly
- 1 – Right Floorboard Assembly
- 2 – 8mm x 40mm Hex Bolts
- 2 – 8mm Hex Nuts

Application(s) >

- Suzuki Volusia 800 01-04
- Suzuki Boulevard M50 05-14

Instruction Manual >

06-1825/06-4325

This product installation may require adjusting the brake pedal and gear shifter. Read all instructions carefully and completely before installing your new Boulevard Products Floor Boards.

1. Remove the stock front foot pegs.
2. Install the Cobra left side floorboard using the supplied 8mm x 40mm bolt and 8mm nut.
3. Repeat step (2) for right side.
4. Check the rear brake assembly & pedal to make sure it is in good working order and does not interfere with floorboard. Note: The rear brake should be checked before every ride.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

Anything's Possible.®