

# COBRA

## Items Supplied >

- 1 - 8mm X 1.25 Nut
- 1 - 10mm 1.25 X 100 Hex Head
- 1 - 12 X 1.75 X 45 Hex Head
- 1 - 12 X 1.75 Nylock Nut
- 1 - Spacer 3/4" OD X 0.40620 X 1.05 Long
- 1 - Set Of Floorboards With Mounts

## Application(s) >

KAWASAKI VULCAN 800A/B 95-05

## Instruction Manual >

06-1920/06-4420

Page 1 of 1

**Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installation.**

1. Remove left and right foot pegs.

### LEFT SIDE FLOORBOARD

2. Replace acorn nut on shift lever shaft just above left foot peg mount with supplied 8mm nut.
3. Install left floorboard assembly over left foot peg bracket using stock bolts.

### RIGHT SIDE FLOORBOARD

4. Remove lower foot peg bracket bolt on right side. Install right floorboard assembly onto stock foot peg mount using supplied bolt and nut to hold floorboard in place. Place supplied spacer between floor board bracket and stock foot peg bracket and bolt in place with supplied bolt.
5. Tighten all hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***