

# COBRA

## Items Supplied >

- 2 - Floorboard Assemblies with Mounts
- 2 - 8mm x 45mm Hex Bolts
- 4 - 8mm Flat Washers
- 2 - 8mm Nylock Nuts

## Application(s) >

- (06-3620) - VT1100 SHADOW 87-96
- (06-3622) - VT1100 AERO 98-02
- (06-3630) - VT1100 ACE 95-99
- (06-3631) - VT1100 ACE TOURER 98-01
- (06-3635) - VT1100 SABRE 00-07

## Instruction Manual >

06-3620/06-3622/06-3630/06-3631/06-3635

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts.
3. Check to make sure that the cotter pins are properly installed and the bolts are tight prior to riding the motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***