

COBRA

Items Supplied >

- 1 – Left Floorboard Assembly W/Mount
- 1 – Right Floorboard Assembly W/Mount

Application(s) >

HONDA VALKYRIE 97-03
HONDA VALKYRIE TOURER 97-00
HONDA VALKYRIE INTERSTATE 97-01

Instruction Manual >

06-3640/06-4640

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Boulevard Products Floorboards

1. Remove your original passenger footpeg mounts (with footpegs still attached) from the frame.
2. Install the Cobra passenger floorboard assemblies in the stock passenger mount location using the original bolts. Tighten the bolts to factory torque specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.