

# COBRA

## Items Supplied >

- 2 - Floorboard Assemblies with Mounts
- 2 - 6mm x 35mm Allen Bolts
- 4 - 6mm Flat Washers
- 2 - 6mm Nylock Nuts

## Application(s) >

HONDA VTX1800R/S 02-UP

## Instruction Manual >

06-3660/06-4660

**Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the top bolt that attaches the left passenger footpeg bracket to the frame. Loosen the bottom bolt. Rotate the bracket so the passenger footpeg mounting pin can be removed. Remove your original passenger foot pegs from the brackets.
2. Install the passenger floorboard assemblies in the stock passenger footpeg location using the supplied 6mm bolts, washers and nylock nuts. Reinstall the bolts removed/loosened in step 1.
3. You can adjust the angle of the passenger floorboard by loosening the bolts that attach the passenger footpegs brackets to the frame. Make sure to retighten bolts after the desired angle is achieved.
4. Check to make sure that the cotter pins are properly installed and the bolts are tight prior to riding the motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***