

COBRA

Items Supplied >

- 1 - Set Of Floorboards And Mounts
- 4 - 8mm x 25mm Allen Bolts

Application(s) >

V-STAR 1100 99-09

Instruction Manual >

06-3740/06-4740

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard mounts into that location using the 8mm x 25mm allen bolts provided. Torque to factory specification.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.