

# COBRA

## Items Supplied >

- 1 - Set Of Floorboards And Mounts
- 4 - 8mm x 25mm Allen Bolts

## Application(s) >

V-STAR 1100 99-09

## Instruction Manual >

06-3740/06-4740

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard mounts into that location using the 8mm x 25mm allen bolts provided. Torque to factory specification.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***