

# COBRA

## Items Supplied >

1 - Set Of Floorboards And Mounts

## Application(s) >

Yamaha V-Star 1300/Tourer 07-14

## Instruction Manual >

06-3745 / 06-4745 / 06-3746 / 06-4746

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle mounting the passenger pegs to the frame.
2. Install the passenger floorboard mounts onto that location using the previously removed factory bolts. Torque to factory specification.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

***Anything's Possible.®***